

A-9

1
3
7
5
8
H

SERIALS 1048, 1111, 1117 & UP

OWNERS MANUAL

IMCO, INC.

AFTON, WYOMING

TABLE OF CONTENTS

		<u>PAGE</u>
I	<u>AIRCRAFT SPECIFICATIONS</u>	
	Engine Specifications	1
	Aircraft Dimensions	1
	Weights	1
	Fuel and Oil	1
	Landing Gear	1
	Airplane Three View	2
II	<u>DESIGN INFORMATION</u>	
	Engine & Propeller	3
	Fuselage & Wings	3
	Landing Gear	4
	Tail Surfaces	4
	Control System	4
	Fuel System	4
	Electrical System	5
	Finish	5
	Cabin Features	5
	Electrical System Schematic	6
III	<u>OPERATING INSTRUCTIONS</u>	
	Preflight	7
	Before Operation	7
	Starting Engine	7
	Warm-Up and Ground Check	8
	Take-Off, Climb, and Level Flight	8
	Cruising	9
	Landing	9
	Securing the Aircraft When Leaving it Unattended	9
	Helpful Suggestions	9
	Flight Manual (Part 3 Certification only)	10A
	Weight & Balance	10B
	Equipment List (Part 3 Certification Only)	10C
IV	<u>GENERAL MAINTENANCE</u>	
	Fuel Requirements	11
	Oil Requirements	11
	Battery Service	11
	Windshield & Windows	11
	Brake and Tire Service	12
	Carburetor Air Filter	12
	Inspections	13
	Leveling & Rigging	19
	Serial Number Plate	19
V	<u>AGRICULTURAL DATA</u>	
	Description	21
	Boom Master Spray System	21
	Aircraft Calibration	22
	Solids Dispersal Equipment	24
	<u>AIRCRAFT WARRANTY</u>	27

